

Oxygen Forensic Suite 2010

Supported phones & features matrix

Feature \ Phones	1 – Nokia and Vertu classic phones	2 - Sony Ericsson classic phones	3 – Symbian S60 platform smartphones	4 - UIQ2 platform smartphones	5 – UIQ3 platform smartphones	6 - Windows Mobile 5/6 devices	7 - Blackberry devices	8- Samsung phones	9- Motorola phones	10- Apple devices	11- Android OS smartphones
Cable connection	Yes	Yes	Yes	-	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Bluetooth connection	Yes	Yes	Yes	Yes	Yes	Yes	-	-	-	NA	-
Infrared connection	Yes	-	Yes	Yes	-	-	NA	-	-	NA	NA
General phone information	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Phonebook	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Custom field labels for contacts	NA	NA	Yes	Yes	Yes	NA	Yes	Yes	NA	NA	Yes
Contact pictures	Yes	-	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Speed dials	Yes	-	Yes	Yes	Yes	-	-	-	-	Yes	-
Caller groups	Yes	-	Yes	Yes	Yes	Yes	-	-	Yes	NA	-
Calendar	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Tasks	Yes	-	Yes	Yes	Yes	-	Yes	-	NA	NA	-
Notes	Yes	-	-	-	-	-	-	-	-	Yes	-
Incoming, outgoing and missed calls information	Yes	Yes	Yes	-	-	Yes	Yes	Yes	Yes	Yes	Yes
GPRS, EDGE, CSD, HSCSD and Wi-Fi traffic and sessions log	NA	NA	Yes	Yes	-	-	-	NA	NA	NA	-

Sent and received SMS, MMS, E-mail messages log	Sent SMS	NA	Yes	Yes	Yes ⁽²⁾	-	-	NA	NA	NA	-
Deleted SMS messages information*	-	-	Yes	-	Yes	-	-	-	-	-	-
Flash SMS information ⁽¹⁾	-	-	Yes	-	Yes	-	-	-	-	-	-
SMS, MMS and E-mail messages in standard folders	Yes	Yes	Yes	Yes	Yes	Yes	-	Yes	Yes ⁽⁶⁾	Yes	Yes ⁽⁶⁾
SMS, MMS and E-mail messages in custom folders	Yes	NA	Yes	Yes	Yes	Yes ⁽³⁾	-	-	NA	NA	-
File system in phone memory and flash card	Yes	Yes	Yes	Yes	Yes	Yes	-	Yes/-	Yes	Yes/NA	-
Photos, videos and voice records	Yes	Yes	Yes	Yes	Yes	Yes	-	Yes	Yes	Yes	-
Geo event positioning	Yes ⁽⁷⁾	Yes ⁽⁷⁾	Yes	Yes ⁽⁷⁾	Yes ⁽⁷⁾	Yes ⁽⁷⁾	Yes ⁽⁷⁾	Yes ⁽⁷⁾	Yes ⁽⁷⁾	Yes ⁽⁷⁾	-
Web Cache	Yes ⁽⁴⁾	-	Yes	-	-	Yes	-	-	-	Yes	-
Web Bookmarks	-	-	Yes ⁽⁵⁾	-	-	-	-	-	-	Yes	-
Phone Activity	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Skype	No	No	No	No	No	Yes	No	No	No	Yes	No

Wi-Fi Connections	No	No	No	No	No	No	No	No	No	Yes	No
Plist Viewer	No	No	No	No	No	No	No	No	No	Yes	No
SQLite database Viewer	No	No	Yes	No	No	No	No	No	No	Yes	Yes
Unicode support	Yes	Yes	Yes	Yes	Yes	Yes	-	Yes	Yes	Yes	Yes
Advanced search through phones database	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

- ⁽¹⁾ - Reading messages information is available in Event Log section. Message must not be older than the number of days specified by "Log duration" parameter in system log application.
- ⁽²⁾ - Only SMS information.
- ⁽³⁾ - Only first-level custom folders.
- ⁽⁴⁾ - Only for Nokia Series 40 phones.
- ⁽⁵⁾ - Only for Nokia Series 60 2nd Edition and 3rd Edition Initial Release smartphones
- ⁽⁶⁾ - Only SMS
- ⁽⁷⁾ - For the photos that have GPS or Cell coordinates

"Yes" means the feature is supported by the software.

"-" means the feature is not supported by the software.

"NA" means the feature is not available for the device.

1 - Nokia and Vertu classic phones:

- Nokia: 1200, 2112, 2115, 2115i, 2127, 2270, 2275, 2280, 2285, 3210, 3310, 3315, 3320, 3321, 3330, 3350, 3360, 3361, 3390, 3395, 3410, 3510, 3570, 3580, 3585, 3590, 3610, 5110, 5130, 5190, 5210, 5510, 6110, 6150, 6190, 6210, 6250, 6310, 6310i, 6320, 6340, 6340i, 6360, 6370, 6385, 6510, 6590, 7110, 7160, 7190, 8210, 8250, 8310, 8390, 8810, 8850, 8855, 8890, 8910, 1506, 1680 Classic, 2125, 2220 Slide, 2320 Classic, 2323 Classic, 2330 Classic, 2600 Classic, 2605, 2608, 2610, 2626, 2630, 2650, 2660, 2680 Slide, 2690, 2700 Classic, 2710 Navigation Edition, 2720 Fold, 2730 Classic, 2760, 2855, 2865, 3100, 3105, 3108, 3109 Classic, 3110 Classic, 3120 Classic, 3125, 3128, 3152, 3155, 3155i, 3200, 3205, 3208 Classic, 3220, 3300, 3500 Classic, 3510i, 3520, 3555, 3560, 3586, 3586i, 3587, 3587i, 3588i, 3589i, 3595, 3600 Slide, 3606, 3608, 3610 Fold, 3710 Fold, 3720 Classic, 3806, 5000, 5070, 6070, 6080, 5100, 5130 XpressMusic, 5140, 5140i, 5200, 5220 XpressMusic, 5300, 5310 XpressMusic, 5330 Mobile TV Edition, 5330 XpressMusic, 5610 XpressMusic, 6010, 6011, 6011i, 6012, 6015, 6020, 6021, 6030, 6060, 6061, 6062, 6066, 6085, 6086, 6088, 6100, 6101, 6102, 6102i, 6103, 6108, 6111, 6112, 6125, 6126, 6131, 6133, 6136, 6151, 6152, 6155, 6165, 6170, 6175i, 6178i, 6200, 6208 Classic, 6212 Classic, 6216 Classic, 6220, 6225, 6230, 6230i, 6233, 6234, 6235, 6245i, 6255, 6260 Slide, 6263, 6265, 6267, 6270, 6275, 6280, 6282, 6288, 6300, 6300i, 6301, 6303 Classic, 6316s, 6500 Classic, 6500 Slide, 6555, 6560, 6585,

6600 Fold, 6600 Slide, 6600i Slide, 6610, 6650, 6651, 6700 Classic, 6750 Mural, 6800, 6810, 6820, 6820, 6822, 7020, 7070 Prism, 7088, 7100 Supernova, 7200, 7210 Supernova, 7210, 7230, 7250, 7250i, 7260, 7270, 7280, 7310 Supernova, 7360, 7370, 7373, 7380, 7390, 7500 Prism, 7510 Supernova, 7600, 7610 Supernova, 7900 Prism, 8208, 8600 Luna, 8800 Arte, 8800 Sirocco Edition, 8800, 8801, 8910i, C1-01, C1-02, C3-00, X2-00, X3.

- Vertu: Ascent 2004, Ascent M 2006, Ascent Ti, Constellation, Signature 2002, Signature 2006, Signature 2008.
- Mobiado: Professional, Professional Executive.

2 - Sony Ericsson classic phones:

- 550im, 658c, 901a, C510, C510a, C702a, C702c, C702i, C901, C902, C902c, C903, C903a, C905, C905c, D750i, K758c, F100i Jalou, F500i, G502, G502c, G705, G705a, J10, J105a (Naite), J105i (Naite), J10i2 Elm, J20 Hazel, J20i Hazel, K500c, K500i, K506c, K508c, K508i, K510i, K510c, K530i, K550i, K550c, K600i, K608i, K610i, K618i, V630i, K630i, K660i, K700c, K700i, K750i, K750c, K770i, K790a, K790i, K790c, K800i, K810i, K818c, K850a, K850i, K858c, S302, S500i, S700c, S700i, S710a, T226, T228, T230, T290c, T290i, T300, T302, T310i, T312, T610, T618, T630, T650i, T68, T68i, T68ie, T700, T707, T707a, T715, T715a, V600i, V640i, V800, V802SE, Z800i, W200i, W200c, W300i, W300c, W350, W350a, W380a, W380i, W395, W508, W518a, W550i, W550c, W580i, W580c, W595, W600a, W600c, W600i, W610i, W610c, W660i, W700i, W700c, W705, W710i, W710c, W715, W760c, W760i, W800i, W800c, W810i, W810c, W830i, W830c, W850i, W880i, W888c, W890i, W900i, W908c, W910i, W980, Xperia Pureness X5, Z1010, Z310a, Z310i, Z500a, Z520a, Z520i, Z520c, Z525a, Z530i, Z530c, Z550i, Z550c, Z555a, Z555i, Z558i, Z558c, Z600, Z608, Z610i, Z710i, Z710c, Z750i, Z770i, Z780i.

3 - Nokia S60/S80/S90 platform smartphones:

- Nokia: 3230, 3250, 3600, 3620, 3650, 3660, 5228, 5230, 5230, 5230, 5232, 5233, 5320 XpressMusic, 5500 Sport, 5530 XpressMusic, 5630 XpressMusic, 5700 XpressMusic, 5730 XpressMusic, 5800 XpressMusic, 6110 Navigator, 6120 Classic, 6121 Classic, 6122 Classic, 6124 Classic, 6210 Navigator, 6220 Classic, 6260, 6290, 6600, 6620, 6630, 6631, 6638, 6650 (smartphone), 6670, 6680, 6681, 6682, 6700 Slide, 6710 Navigator, 6720 Classic, 6730 Classic, 6760 Slide, 6788, 6788i, 6790 Slide, 6790 Surge, 7610, 7650, C5-00, E50, E5-00, E51, E52, E55, E55, E60, E61, E61i, E62, E63, E65, E66, E66, E70, E71, E71x, E72, E73 Mode, E75, E90, N70, N71, N72, N73, N75, N76, N77, N78, N79, N80, N81, N82, N85, N86, N90, N91, N92, N93, N93i, N95 8GB, N95, N96, N97 mini, N97, N-Gage QD, N-Gage, X5-00, X5-01, X6, 9300, 9300i, 9500, 7700, 7710.
- Samsung: GT-i7110, GT-I8150, INNOV8 (i8510), OMNIA HD, SGH-D700, SGH-D710, SGH-D720, SGH-D728, SGH-D730, SGH-G810, SGH-i400, SGH-i450, SGH-i520, SGH-i550, SGH-i560, SGH-i570, SGH-L870, SGH-Z600.
- Sony Ericsson Satio
- Panasonic: X700, X800.
- Siemens: SX1.
- LG: KT-615

4 - UIQ2 platform smartphones:

- Sony Ericsson: P800, P802, P900, P908, P910i, P910c, P910a.
- Motorola: A1000, A1010, A920, A925.
- Benq: P30, P31.
- Nokia: 6708.

5 - UIQ3 platform smartphones:

- Sony Ericsson: G700, G700c, G700i Business Edition, G702, G900, M600i, M608c, P1c, P1i, P990i, W950i, W958c, W960i
- Motorola: MotoRizr Z8, MotoRizr Z10.

6 - Windows Mobile 5/6 devices:

- Acer: Acer Windows Mobile, beTouch E101, beTouch E200, c510, c530, c531, DX650, F900, n300, N310, n311, n320, n321, NeoTouch
- Airis: Airis Windows Mobile, T610, T620
- Amoi: Amoi Windows Mobile, E75, E76, E78, E850, E860
- AnexTEK: AnexTEK Windows Mobile, moboDA 3160, moboDA 3360, moboDA 3380, SP310
- AnyDATA: AnyDATA Windows Mobile, ASP-210C, ASP-500 GA, ASP-505 A
- Asus: Asus Windows Mobile, Lamborghini ZX1, M530w, M536, M930, Mars II, MyPal A626, MyPal A632, MyPal A636, MyPal A636N, MyPal A639, MyPal A686, MyPal A696, P305, P320, P525, P526, P527, P535, P550, P552w, P560, P565, P735, P750
- AT Mobile: AT Bear, AT Cobra, AT Eagle, AT Falcon, AT Mobile Windows Mobile, AT Pelican
- ATT: 8525, ATT Windows Mobile, BlackJack II, Moto Q Global, Palm Treo, Pantech Duo, Tilt
- Audiovox: 6700, Audiovox Windows Mobile, XV6700
- BenQ: BenQ Windows Mobile, E72, P51
- Cingular: 2125, 3125, 8125, Cingular Windows Mobile
- Dell: Dell Windows Mobile, X51, X51v
- Dopod: 310, 577W, 586W, 595, 818 Pro, 838 Pro, 838, 900, C500, C720W, C730, D600, D802, D810, Dopod Windows Mobile, M700, P100, P800W, S300, T5399, U1000
- Eten: Eten Windows Mobile, G500, G500+, Glofiish M750, Glofiish M800, Glofiish M810, Glofiish V900, Glofiish X500, Glofiish X500+, Glofiish X600, Glofiish X610, Glofiish X650, Glofiish X800, Glofiish X900, M550, M600, M600+
- Everex: Everex Windows Mobile, NEON
- Fifth Media: A308, Fifth Media Windows Mobile
- Fly: Fly Windows Mobile, IQ-110
- Fujitsu Siemens: Fujitsu Siemens Windows Mobile, Pocket LOOX C550, Pocket LOOX N100, Pocket LOOX N110, Pocket LOOX N500, Pocket LOOX N520, Pocket LOOX N560, Pocket LOOX T810, Pocket LOOX T830
- Gigabyte: Gigabyte Windows Mobile, g-Smart i, g-Smart i+, g-Smart i120, g-Smart i128, g-Smart i300, g-Smart i350, g-Smart MS800, g-Smart MS804, g-Smart MS808, g-Smart MS820, g-Smart MW700, g-Smart MW702, g-Smart MW720, g-Smart MW998, g-Smart Q60, g-Smart t600, g-Smart
- Hewlett-Packard: Hewlett-Packard Windows Mobile, iPaq 111 Classic, iPAQ 114 Classic, iPaq 211 Enterprise, iPAQ 214 Enterprise, iPAQ 500, iPAQ 510, iPAQ 512, iPAQ 514, iPAQ 614 Business, iPAQ 614c, iPaq 910, iPAQ 914c, iPAQ hw6910, iPAQ hw6915, iPAQ hw6920, iPAQ hw6925, iPAQ hw6940, iPAQ hw6945, iPAQ hw6965, iPAQ hx2190, iPAQ hx2195, iPAQ hx2490, iPAQ hx2495, iPAQ hx2790, iPAQ hx2795, iPAQ rw6815, iPAQ rw6818, iPAQ rw6828, iPAQ rx1950, iPAQ rx1955
- HTC: Advantage X7500, Advantage X7501, Advantage X7510, Advantage, Apache, Artemis, Athena, Atlas, Breeze, Cavalier, Elf, Erato, Excalibur, Faraday, Galaxy, Gene, HD2, Herald, Hermes, HTC Windows Mobile, Imagio, Kaiser, Libra, Love, MAX 4G, Mogul 6800, Mogul, Monet, Mteor, Muse, Nike, Omni, Oxygen, P3300, P3400, P3470, Panda, Pharos, Prophet, Pure, S1200, S630, S710, Sedna, Sirius, Star Trek, Tilt 2, Titan, Tornado, Touch CDMA, Touch Cruise P3650, Touch Cruise, Touch Cruise2, Touch Diamond P3700, Touch Diamond, Touch Dual, Touch P3452, Touch Pro, Touch Pro2, Touch Viva 2223, Touch, Trinity, TyTN, Tytn-II, Universal, Volans, Vox, Wings, Wizard
- i-mate: i-mate Windows Mobile, Jama 101, Jama 201, Jama, Jamin, JAQ, JAQ3, JAQ4, JasJam, JasJar, K-Jam, PDA-L, PDA-N, SmartFlip, SP5, SP5m, SPjas, SPL, Ultimate 5150, Ultimate 6150, Ultimate 7150, Ultimate 8150, Ultimate 8502, Ultimate 9150, Ultimate 9502
- i-teq: Bond, i-teq Windows Mobile, Laser, X-Bond

- IzenMobile: IzenMobile Windows Mobile, KRMA, KSMT
- Kinpo: Everex NEON, iDO S601, iDO S630, Kinpo Windows Mobile, SP70, SP70R, SP90
- Lenovo: ET960, ET980, i921, Lenovo Windows Mobile
- LG: eXpo, Fathom, Incite, KC1, KS20, LG Windows Mobile
- Mio: A502, A702, Mio P550, Mio P560, Mio Windows Mobile, P360
- Mitac: A201, A501, A701, Mitac Windows Mobile
- Motorola: Franklin, MC35, MC9000, MC9090-G, MC909X-K, MC909X-S, MOTO Q q9, MOTO Q11, MOTO Q9C, MOTO Q9m, Motorola Windows Mobile, Norman, Q GSM, Q, Q8, Q9, Q9h
- MWG: Atom V, MWG Windows Mobile, Zinc II
- Neonode: N2, Neonode Windows Mobile
- O2: O2 Windows Mobile, XDA Argon, XDA Atom Exec, XDA Atom Life, XDA Atom Pure, XDA Atom, XDA Cosmo, XDA Exec, XDA Flame, XDA Graphite, XDA IQ, XDA mini S, XDA Neo, XDA Nova, XDA Orbit, XDA Orion, XDA Stealth, XDA Terra, XDA Trion, XDA Zinc
- Okwap: K728, K868, K869, K871, Okwap Windows Mobile, S868
- Orange: Orange Windows Mobile, SPV C100, SPV C200, SPV C600, SPV C700, SPV E600, SPV E610, SPV E650, SPV F600, SPV M3000, SPV M3100, SPV M5000, SPV M600, SPV M650, SPV M700
- ORSiO: G735, N725 GPS, N725, ORSiO Windows Mobile, P745
- Palm: Palm Windows Mobile, Treo 500, Treo 700w, Treo 700wx, Treo 750, Treo 750v, Treo 800w, Treo Pro
- Pantech: Matrix Pro, Pantech Windows Mobile, PN820
- Paragon Wireless: Hipi-2200, Hipi-2300, Paragon Wireless Windows Mobile
- Pharos: 600 GPS Phone, Pharos Windows Mobile, Traveller GPS 525
- Pocket Navigator: PN-3550, PN-3560, PN-P201, PN-P550 A, PN-P550, Pocket Navigator Windows Mobile
- Psion Teklogix: Ikon, Psion Teklogix Windows Mobile, WORKABOUT PRO G2, WORKABOUT PRO
- Qool Labs: QDA Icon, QDA Lite, Qool Labs Windows Mobile, Twins 178
- Qtek: 8300, 8310, 8500, 8600, 9000, 9100, 9600, G100, G200, Qtek Windows Mobile, S200, S310
- Quanta: Apollo, Atom Exec, Atom Pure, Atom, Quanta Windows Mobile
- Quest: Pocket PC6700, Quest Windows Mobile
- RoverPC: C6, C7, E5, Evo X8 Black, Evo X8 White, Evo X8, G5, G6, M5, N6, N7, P6, P7, Pro G8 Black, Pro G8 White, Q5, Q6, Q7, R5, RoverPC Windows Mobile, S5, S6, S7, S8 Black, S8 Lite, S8, W5, X7
- Samsung: Amoled, B7300 Omnia Lite, B7620 Armani, Epix, i200, Intrepid, Jack, Omnia II, Omnia, Propel Pro, Saga, Samsung Windows Mobile, SGH-i200, SGH-i310, SGH-i320, SGH-i600, SGH-i710, SGH-i718, SGH-i718+, SGH-i720, SGH-i728, SGH-i740, SGH-i750, SGH-i760, SGH-i780, SGH-i900 (WITU), SPH-i325, WiTu i900
- Sharp: Sharp Windows Mobile, W-ZERO3 (WS004SH)
- Socket Mobile: SoMo 650 DX, SoMo 650
- Sony Ericsson: Sony Ericsson Windows Mobile, XPERIA X1
- Sprint: Ace, Sprint Windows Mobile
- TDS: Nomad 800B, Nomad 800L, Nomad 800LC, Nomad 800LE, Ranger 300X, Ranger 500X, TDS Windows Mobile
- T-Mobile: Dash, MDA compact IV, MDA Pro, MDA Vario, Shadow, T-Mobile Windows Mobile, Wing, Wings US
- Toshiba: Portege G500, Portege G710, Portege G810, Portege G900, Portege G910, Toshiba Windows Mobile
- Velocity Mobile: 103, 111, Velocity Mobile Windows Mobile
- Verizon Wireless: PN-820, SMT5800, Verizon Wireless Windows Mobile, XV6800, XV6900
- Vodafone: 1210, V1240, Vodafone Windows Mobile, VPA IV
- Voxtel: Voxtel Windows Mobile, W210, W420, W520, W740

7 - Blackberry devices:

- 8100, 8110, 8120, 8130, 8300, 8310, 8320, 8330, 8350i, 8500, 8520, 8530, 8800, 8820, 8830, 8900, 9500, 9520 or 9550, 9520, 9530, Bold, Flip 8220.

8 - Samsung phones:

- SGH-A226, SGH-A227, SGH-A237, SGH-D500, SGH-D500E, SGH-D508, SGH-D510, SGH-D600, SGH-D600E, SGH-D608, SGH-D610, SGH-D618, SGH-D820, SGH-D820E, SGH-D828, SGH-D828E, SGH-D888+, SGH-D900, SGH-D900i, SGH-D908, SGH-D908i, SGH-E200, SGH-E200B, SGH-E208, SGH-E208B, SGH-E236, SGH-E250, SGH-E250D, SGH-E250W, SGH-E251, SGH-E251C, SGH-E256, SGH-E258, SGH-E258D, SGH-E340, SGH-E348, SGH-E350, SGH-E358, SGH-E360, SGH-E368, SGH-E370, SGH-E370L, SGH-E378, SGH-E380, SGH-E388, SGH-E390, SGH-E398, SGH-E480, SGH-E488, SGH-E500, SGH-E508, SGH-E590, SGH-E598, SGH-E640, SGH-E648, SGH-E690, SGH-E698, SGH-E730, SGH-E736, SGH-E738, SGH-E740, SGH-E747, SGH-E748, SGH-E750, SGH-E758, SGH-E760, SGH-E768, SGH-E780, SGH-E788, SGH-E830, SGH-E838, SGH-E840i, SGH-E848i, SGH-E890, SGH-E898, SGH-F110, SGH-F118, SGH-F150, SGH-F158, SGH-F250, SGH-F250L, SGH-F258, SGH-F260, SGH-F265, SGH-F268, SGH-F270, SGH-F270L, SGH-F278, SGH-F480L, SGH-F488E, SGH-G600, SGH-G608, SGH-G618, SGH-G808E, SGH-I858, SGH-J150, SGH-J158, SGH-J210, SGH-J218, SGH-J700, SGH-J700L, SGH-J706, SGH-J708, SGH-J708C, SGH-J808E, SGH-L250, SGH-L258, SGH-L310, SGH-L318, SGH-L600, SGH-L608, SGH-L750, SGH-M150, SGH-M158, SGH-M3510, SGH-M610, SGH-M618, SGH-P180, SGH-P200, SGH-P220, SGH-P240, SGH-P260, SGH-P780, SGH-P788, SGH-P850, SGH-P858, SGH-T219, SGH-T229, SGH-T301, SGH-T309, SGH-T329, SGH-T336, SGH-T339, SGH-T409, SGH-T429, SGH-T439, SGH-T459, SGH-T509, SGH-T619, SGH-T709, SGH-T729, SGH-T739, SGH-T809, SGH-U708E, SGH-U808E, SGH-U900L, SGH-U908E, SGH-X437, SGH-X576, SGH-X670, SGH-X678, SGH-X690, SGH-X698, SGH-X700, SGH-X708, SGH-Z240, SCH-U350 Smooth, SGH-A137, SGH-A26A, SGH-A437, SGH-B110, SGH-B110L, SGH-B130, SGH-B130S, SGH-B138, SGH-B210, SGH-BC01, SGH-C160, SGH-C160B, SGH-C160G, SGH-C161, SGH-C165, SGH-C168, SGH-C168B, SGH-C180, SGH-C280, SGH-C288, SGH-C327, SGH-C420, SGH-C425, SGH-C426, SGH-C450, SGH-C458, SGH-CC03, SGH-D488, SGH-E100, SGH-E108, SGH-E1110, SGH-E330, SGH-E330C, SGH-E330N, SGH-E335, SGH-E338, SGH-E420, SGH-E428, SGH-E630, SGH-E630C, SGH-E638, SGH-E700, SGH-E700A, SGH-E708, SGH-E746, SGH-E800, SGH-E800C, SGH-E808, SGH-E820, SGH-M110, SGH-M120, SGH-M130L, SGH-M140, SGH-S500, SGH-S508, SGH-T101, SGH-T101G, SGH-T109, SGH-T209, SGH-T319, SGH-T329, SGH-X100, SGH-X108, SGH-X460, SGH-X490, SGH-X495, SGH-X497, SGH-X540, SGH-X550, SGH-X560, SGH-X560L, SGH-X566, SGH-X600, SGH-X600A, SGH-X608, SGH-X620, SGH-X628, SGH-X640, SGH-X648, SGH-X650, SGH-X658.

9 – Motorola phones:

- T720, T725 A810, MOTO W388, MOTO ZN200, MOTOROKR EM28 (EM330), MOTOROKR EM30, MOTOZINE ZN5, ROKR EM25 (MOTO EM325), VE538 A845, C380, C650, C980, E1000, E1070, E380, E398, E550, E770, L2, L6, MOTO Z9 (Z9N), MOTOACTV W6, MOTOKRZR K1, MOTOKRZR K1m, MOTOKRZR K3, MOTOPEBL U3, MOTOPEBL U6, MOTORAZR maxx V6, MOTORAZR V3 (CLDC 1.0), MOTORAZR V3 (CLDC 1.1), MOTORAZR V3e, MOTORAZR V3i, MOTORAZR V3m, MOTORAZR V3re, MOTORAZR V3t, MOTORAZR V3v, MOTORAZR V3xx, MOTORAZR2 V8, MOTORAZR2 V9, MOTORAZR2 V9x, MOTORIZR Z3, MOTOROKR E1, MOTOROKR E8, MOTOSLVR L7, MOTOSLVR L72, MOTOSLVR L7i, L7e, MOTOSLVR L9, V1050, V1100, V180, V195, V197, V220, V300, V360, V400, V500, V550, V551, V600, V620, V635, V80, V975, V980, W230, W270, W490.

10 – Apple devices:

- iPad, iPhone, iPhone 3G, iPhone 3GS, iPod Touch.

11 - Android devices:

- Archos: Internet Tablet
- Camangi: WebStation
- Dell: Mini3i
- DoCoMo: HT-03A
- Era: G1
- General Mobile: DSTL1
- Google: Android Phone
- Highscreen: PP5420
- HTC: Click, Dream, Hero, Magic, Tattoo
- Huawei: U8220, U8230
- Lenovo: oPhone
- LG: GW620 Eve, KH5200
- Motorola: BackFlip, CLIQ, DEXT, Droid, Heron, Milestone, Motorola, Sholes
- Philips: V900
- Qigi: i6
- Rogers: Dream
- Samsung: GT-I5700 Galaxy, GT-I7500 Galaxy, InstinctQ, Moment, Spica
- SciPhone: N19, N21
- Sony Ericsson: XPeria X10, XPeria X3
- Tiger: G3
- T-Mobile: G1, G2, myTouch 3G, Pulse